



Details shown illustrate typical situations and are not intended to cover specific cases. Refer to project plans for particular requirements at various locations.

Do not disturb or destroy any Right-of-Way markers.

Provide 12 inches to 15 inches of clear space between adjoining end post installations.

- ① Review the exact location of the posts with the Engineer prior to construction.
- ② Contractor has the option to install fence continuously beneath bridges when practical.
- ③ Contractor has the option to install fence over the top of the culvert if this dimension is a minimum of 50 feet.
- ④ Floodgate, Floodplain, or Channel Crossing Fence as specified on project plans. Review the exact location of the post with the Engineer prior to construction.
- ⑤ Construct corners with posts on the inside, unless wire is cut and wrapped.

 <b>STANDARD ROAD PLAN</b>	REVISION	
	1	10-20-15
	<b>MI-101</b> SHEET 1 of 1	
REVISIONS: Replaced the DOT logo in the title block with the new version.		
 APPROVED BY DESIGN METHODS ENGINEER		
<b>FENCING LAYOUT</b>		