


The EXIT NUMBER PANEL shall normally be positioned above the guide

sign aligned with the edge of the guide sign indicating direction of

1. IF THE BOLT HOLES IN THE TOP PANEL AND THE BOTTOM PANEL OF THE TWO SIGNS LINE UP, PANEL BOLTS ARE TO BE USED

2. IF THE ANGLE FASTENERS CAN NOT BE HORIZONTALLY PLACED AS SHOWN, THEY CAN BE MOVED SO AS TO SECURELY HOLD THE TOP SIGN.

EXIT GORE SIGNS



NOTE: THE EXIT PANEL SHALL BE CENTERED ABOVE M9-2.



STANDARD ROAD PLAN RI

PLACEMENT DETAILS
OF EXIT NUMBERED SIGN
ABOVE ANOTHER SIGN