



NOTES:

Reinforced concrete beam utility line support to be used when new sewer excavation is crossing under an existing utility line (sewer lines, water lines, gas lines, etc.) as directed by the Engineer.

Allow concrete to cure a minimum of 48 hours before placing backfill material.

Special design required for trench width greater than 7 feet or trench depth greater than 15 feet.

 SUDAS	REVISION	
	NEW	10/21/08
	FIGURE 3010.902	
SHEET 1 OF 1		
REINFORCED PCC BEAM UTILITY LINE SUPPORT		