



FIGURE 9040.104 SHEET 1 OF 1

- ① Secure blanket to ground according to manufacturer's recommended anchoring pattern and anchor density (minimum 1.7 anchors per square yard).
- ② Install staples at 1 foot on center.
- ③ Install staple checks at 100 foot intervals for channel slopes less than 2.5%.
- ④ Install blanket checks for the following slopes:
 2.5% - 3% 100 ft. intervals
 3% - 5% 50 ft. intervals
 5% - 7% 25 ft. intervals

	REVISION
	3 2025 Edition
	9040.104
SHEET 1 of 1	

SUDAS Standard Specifications
ROLLED EROSION CONTROL PRODUCT (RECP)
INSTALLATION IN CHANNELS