21A-6

## **Open Explorer to Working Directory**


Design Manual Chapter 21 Automation Tools Instructions

Originally Issued: 08-29-08

Revised: 04-30-09

This command is accessed through **Geopak**: D&C Manager, as shown below.

(If the item is not found as shown, use the D&C > Edit > Find tool to locate it.)



Double-click the **Open Explorer to current working directory** item and the <u>Microsoft Windows Explorer</u> window will open to the directory where the current active <u>MicroStation</u> file is located, (which is the current working directory). This will save much time, as compared to accessing the current working directory using the manual process of:

"Right-click Start > Explore All Users > W > Projects > ProjectDirectory > ...",

and possibly going even deeper into the directory structure.