





PERSPECTIVE VIEW



CROSS SECTION

- ① 2 in. x 8 in. pressure treated lumber. Ensure top of spreader is level. Adjust as necessary during construction to maintain spreader in a level condition.
- ② Grade as required to prevent flow around the ends of spreader.
- ③ Length and width as specified.

 SUDAS	REVISION	
	NEW	10/17/06
	FIGURE 9040.9	
	SHEET 1 OF 1	
LEVEL SPREADER		