



NOTE:
Fabric shall be placed on Roadway side of posts. For certain curves, stream crossings or other locations specifically directed by the Engineer, fabric may be placed on the Property side of posts.


TYPICAL PLAN OF FENCE









TYPE 39 FENCE



TYPE 47 FENCE




END POST WIRE WRAP



DETAILS OF BRACE WIRE INSTALLATION

- 1 Make a minimum of four tight wraps back around itself. Ends of the wrap to be trimmed flush.
- 2 Set staples cross-wise to the grain. Staples are to be driven tight at pull posts. All other wood post staples shall be driven firm, but loose enough to allow lateral movement of the wire.
- 3 Approved fence fabric wire splice.
- 4 A tension curve consists of a "U" shaped crimp in the fence wires. It has the same effect as a spring. Stretch to 50% removal of the factory crimp.



All dimensions given in millimeters unless noted.

M	Iowa Department of Transportation Highway Division	
	STANDARD ROAD PLAN RC-8B(1)	
	REVISION: Remove barbed wire.	REVISION NO. 1
	APPROVED BY DESIGN METHODS ENGINEER <i>Deanna Muford</i>	REVISION DATE 04-18-06
	FIELD FENCE CONSTRUCTION (Sheet 1 of 2)	